### **SPL-G LED street luminaire**

### **Mounting instruction**



















IP 66

Ta -40°C +50°C

## IMPORTANT SAFEGUARDS READ AND FOLLOW ALL SAFETY INSTRUCTIONS

- 1. The luminaire is not allowed to be placed in the water or close to fire resource and high temperature place.
- 2. Before installing this fixture or doing any maintenance, make sure to turn off the power supply at the circuit breaker or fuse box.
- 3. Make sure that the luminaire is not damaged before install and use. If the glass is broken or damaged it must be replaced.
- 4. Only the authorized electrician can install the luminaire, and the wire should comply with the national standards.
- 5. Input cable can be 2, 3, 4 or 5 cores and the min cross-sectional area of the conductor should be 1.5 mm2. The input cable should meet requirements of IEC 60227 or IEC 60245.
- 6. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent in order to avoid a hazard.
- Check to make sure that all the fixture connections have been properly made and the fixture is grounded to avoid potential electrical shocks.
- 8. The light source of luminaire is non-user replaceable. It can only be replaced by the manufacturer or his service agent.



Caution, Risk of Electric Shock. Disconect all power sources before servicing.

#### **MAINTENANCE OF LUMINAIRE**


Maintenance of luminaire must be done accorrding the standard CIE 154-2003.

Recommended period of maintenance - every 3-4 years.

Cleaning must be done with soft material and soapy water.

Do not use agressive chemicals or solvents!

#### **Product dimensions:**




Projected area - 0,02 m<sup>2</sup> max. The max mounting height - 10 m

#### MPL, MPL-T parameter table:


LED quantity	8 - 16
Power	10-50W
Weight max	3.2 kg


#### Electrical scheme:





## **Mounting instructions SPL-G**







# **Mounting instructions SPL-G**

